

NOTICE OF ASSEMBLE

Tips for assembling

- 1. Picures shown on the package may be slightly different from the actual product.
- 2.All the materials are taken in the operation step, put the remaining materials back into the original pocket until the installation is completed. (Avoid material loss during installation)
- 3. The dimensions indicated in the step diagram are "cm".
- 4. If there have template paper material, please cut the material according to the template to avoid mistakes...
- 5. According to the part rule example at the bottom of this page, refer to the part on the part number drawing, find the material object and compare with the material list, confirm and install. (Wooden parts only)
- 6. Glue should not be applied too much, so as not to dry longer, overflow will affect the effect of the finished product.
- 7. Part shapes may differ from the photographs depending on the production batch.

Tips For Assemble Wooden Piece



Shave with a knife on the connection point gently, that you can take it out.




Use knife to smooth out burrs.



Or use sandpaper to

Testing on LED function

Be sure to test the LED lights before making the lighting, note that the LED white wire to the negative, gray wire to the positive reference to the following figure operation test.



correct polarity.

How to assemble the battery holder



1. Material and tools needed: - Battery holder, LED bulb tape, screw driver and 2 piece AAA size battery(not provided)



2. Use screw driver and take the lid off from the battery holder.



3. Insert the battery take notes on the polarity.



4. Connect the red wire to grey wire. Connect



5. Wrap the exposed wire with the tapes.



6. Place the box lid and fastness with screw driver.

Example of parts rule:

1. The A01 is in the color box: The B01 is in the B Baa. The C01 is in the C Baa. etc. (Note: The printing paper that we mention in step are in the PP bag and parts number is A12-01) 2.The B11, B17, B18, B19, C02, C03, C07, C08, C12, C13, C14, C15, C16, C17 are in A Bag A13.


Cont	ents		
Name	Material Package	Name	Material Package
Printing Paper	They are total 6 pieces of A4 paper, 1 piece of single printing A5 printing paper and template paper in A Bag A12	Door & Window	D Bag+E Bag+Printing Paper +Template Paper
		Advertising Lights Board	D Bag+G Bag+Printing Paper
Auto Sushi Table	B Bag+Printing Paper	Lantern	B Bag+E Bag+F Bag +Printing Paper
Tatami Dining Table	B Bag+Printing Paper	Umbrella	E Bag+F Bag+Printing Paper
High Chair	B Bag+E Bag+Printing Paper	Art Flower Arrangement	E Bag+F Bag+Printing Paper
Seat Chair	B Bag+E Bag+Printing Paper	Potted Plants	E Bag+F Bag+Printing Paper
Dish & Shusi Box	Printing Paper	Small Parts	E Bag+F Bag+Printing Paper +Template Paper
Sushi	B Bag+E Bag+Printing Paper +Template Paper	Roof & Paper Lantern	A Bag+D Bag+E Bag+F Bag+ Printing Paper
Sushi Roll	B Bag+E Bag+F Bag +Printing Paper +Template Paper		
& Pot Rice		The Frame Of The First Floor	A Bag+D Bag+E Bag+F Bag +Printing Paper
Wine Bottle & Wine Cabinet	C Bag+E Bag+F Bag+ Printing Paper +Template Paper		
		The Frame Of The Second Floor	A Bag+D Bag+F Bag+G Bag +Printing Paper
Showcase	A Bag+C Bag+E Bag +Printing Paper +Template Paper		
		Assemble the Battery Box	G Bag+Printing Paper
Wooden Shoes	C Bag+Printing Paper		
Takeaway Rack	C Bag+E Bag+Printing Paper		
Batten & Doorplate	C Bag+Printing Paper		
Menu & Flag & Signboard	C Bag+Printing Paper		



Thumbnail of material list (reference only)







Thumbnail of printing paper & template paper (reference only)



Symbol description used

















Pay attention to the direction of installation material B stick to material A




















to center dotted


to the middle

Pay attention to the direction of installation material A stick to material B





















































A12-06 nang tag)







Add dining table, seat































(Pay attention to the light line.)





Statement: the lamp wires cannot be inserted into the output socket.

- Can use 7 batteries
 Please notice the place of anode and cathode when pit in the batteries
 Rechargeable batteries are not blunt electricity
 Rechargeable batteries can only be charged under adult supervision
- - Rechargeable batteries should be removed from
- the toy before charging – Different types of batteries cannot mix;
 - Do not mix new batteries in use with semi-used batteries.
- - Run out of battery should be removed from the toy.
- The power shall not be short circuit.



Dust cover (upgrade version accessories need to be purchased separately)



Ratio: 1:10 H04 plexiglass (transparent) 22*20*0.18cm 2pieces




Ratio: 1:10 H05 plexiglass (transparent) 20*17.14*0.18cm 2pieces



Ratio: 1:10 H06 plexiglass (transparent) 22*17.5*0.18cm 1pieces



1. Take out the plexiglass, and then tear off each piece of plexiglass kraft paper.



2. Put the plexiglass of ripped kraft paper stick up as shown in the picture, make a dust cover.

